

I Humidity Thermometer (For both desk and wall mounting)



Technical parameter:

1. Display method: big screen LCD display
2. Temperature range for measuring and display: $-50^{\circ}\text{C}\sim+70^{\circ}\text{C}$
3. Temperature error: $<\pm 0.5^{\circ}\text{C}$
4. Humidity range for display: 20%~90%.
When humidity is more than 90%, it displays HI%.
When humidity is less than 20%, it displays LO%.
5. Humidity error: $<\pm 3\%$
6. Overall size (Width x height x thickness): 97mmx106mmx20mm

Function:

1. Measuring and displaying temperature, humidity and time.
2. Memory function: Memory and displaying the Max. temperature & humidity, and the min. temperature & humidity in latest 24 hours.
3. Displaying the month, day, hour and minute.
4. $^{\circ}\text{C}$ and F switch freely.
5. Alarm clock function.

How to use:

1. **Battery:** Installing one No. 7 battery in the battery house according to the mark. The screen displays temperature, humidity and time (hour, minute) immediately.
2. **$^{\circ}\text{C}$ or F selection:** press the button of $^{\circ}\text{C}/\text{F}$ in the back of thermometer to choose temperature unit you want.
3. **Time setting:** Press "MODE" key for 3 seconds, "hour" starts glittering, press "ADJ" key to set the "hour". Press "MODE" key again, "minute" starts glittering, press "ADJ" key to set the "minute". Press "MODE" key again, "month" starts glittering, press "ADJ" key to set the "month". Press "MODE" key again, "day" starts glittering, press "ADJ" key to set the "day". Press "MODE" key again to complete time setting.
4. **Switch of "month/ day" and "hour/minute":** Normally it displays in mode of "hour /minute", press and release "MODE" key, the display mode will switch to "month /day", press "MODE" key again or no pressing "MODE" key for more 10 seconds, it will return to normal display mode of "hour/minute".
5. **"MEMORY" key:** Press "MEMORY" key in normal working condition, it will display the Max. temperature & humidity in latest 24 hours. Press "MEMORY" key again, it will display the Min. temperature & humidity in latest 24 hours. Press "MEMORY" key again, it will return to normal display of time/ temperature /humidity. If you want to clean up the record of the Max. temperature & humidity and the Min. temperature & humidity in latest 24 hours, press "MEMORY" key in normal working condition, it displays the Max. temperature & humidity in latest 24 hours, then press and release "ALM/CLEAR" key in the back of the thermometer for clearing, then return to normal display automatically. To clear up the Min. temperature & humidity in latest 24 hours in the same way as the above. After clearing, the thermometer will memory and display the new max. temperature & humidity, and the new min. temperature & humidity.
6. **Clock alarm function:** press "ALM/CLEAR" key in the back of the thermometer for 3 seconds, "hour"

starts glittering, press “ADJ” key to adjust value you want. Press “ALM/CLEAR” key again, “minute” starts glittering, press “ADJ” key to adjust value you want. Then press “ALM/CLEAR” key to confirm the setting time, and the thermometer return to the normal display mode of “hour and minute”. When clock alarms, press any key to stop alarming, in this case, the setting time is still valid, the sign “•)))” still displays in the thermometer. It will alarm when it reaches the setting time next time. In normal working condition, press “ALM/CLEAR” key to display the set alarm time.

Press “ADJ” key to cancel the alarm clock function, at this time, the sign “•)))” disappeared.

7. Installation:

- (1). To be used on the table: Unfold the bracket in the back of the thermometer for standing
- (2). To be hung on the wall: Hit a proper nail into the wall, then hang up the thermometer with the installing hole in the back.